

TEMPORARY LOCKING KIT INSTRUCTIONS

In order to lock the lid shut of the new All Metal Consumer Unit, Electrium recommend that two locking brackets & padlocks are fitted to both ends of the consumer unit door to prevent unauthorised access, follow the instructions set out below:

- a) Remove the push-on fix washers from the underside of the lid screws shown in Fig 1.
- b) Insert the locking brackets between the lid and lid screw as shown in Fig 1.




Fig 1

- c) Close the lid, insert the padlocks through the hole in the brackets and back down the open slot as shown in Fig 2.
- d) Close the locks shut. This will now prevent the lid from opening until the padlocks are released.




Fig 2

Note: The temporary locking kit is only compatible with a 3mm shackle / shank Padlock shown [sold separately]